

Setting the time and date

For DCS, iDCS and OS7XXX series Samsung phone systems

Without lifting the handset

Hit the transfer button and then dial 200. When asked for the passcode enter 1234. The display will show disabled, enter 1 to change it to enabled and hit the transfer button again.

Now hit the transfer button and dial 505. The display will show the current date and time in the top row and WMMDDYY:HHMM

Enter the new information as follows

W = Day of the Week (1-7; the week begins on Monday and ends on Sunday)

MM = Month (1-12)

DD = Day of the month (01-31)

YY = Last two digits of the year

HH = Hour (use 24 hour clock)

MM = Minutes (00-59)

Hit the transfer Button to set the time and date. The phone system returns to normal operation.